

Steel Tank Installation Guide.

To ensure these steel tanks are installed correctly. Please follow this guide along with further installation & warranty information in the booklet provided with the tank. You can also find a step by step installation video for these tanks by scanning the QR code below.



Bunded Steel Tanks



- 1 - 1.5" tank contents gauge port
- 2 - 2" fill point or spare port
- 3 - 1.5" bund contents gauge port
- 4 - 2" fill point or spare port
- 5 - 1" suction port
- 6 - 2" 'U' vent - tank to bund
- 7 - 2" bund vent

Single Skin Steel Tanks



- 1 - 2" fill point or vent port
- 2 - 1.5" bund contents gauge port
- 3 - 2" fill point or vent port

Bunded Steel Tank

**1**

1.5" Gauge Port

Suitable for fitting tank contents gauge.

**2**

2" Fill Point

Supplied with a drip cap and chain for security and usability.

**3**

Spare Connections

Replace temporary **Red Plastic Bungs** with the **Grey Metal Bungs** inside the fittings bag.

**4**

2" Bund Vent

Supplied with aluminium vent cap.

**5**

Bottom Outlet

1" BSPF bottom outlet for connecting tank to heating system.

